BACKLIT PANELS
INSTALLATION MANUAL

⚠ Safety Notice:

① Electrical installation should be done by registered electrician.
② Disconnect the luminaire from supply and until luminaire is cooled down, before replacement of the driver.
③ Never touch the lamp while luminaire is switched on.
④ In any case of malfunction disconnect luminaire from supply immediately, don't try to repair the luminaire yourself, repair should only be done by registered electrician or official service agent.

1.



2.



3.



4. Connected driver to mains with a suitable junction box (not included):



Live (L) - Brown
Neutral (N) - Blue

5.





6.



7.



8.



9.



For Codes

954-030, 954-031, 954-032, 954-033, 954-034, 954-035
954-038, 954-039, 954-040, 954-041, 954-042, 954-043

TCF: INT0106 Greece/Europe

Agios Adrianos, 21100 Nafplio Greece / Europe | Tel.: +30 2752 091136 | elmasco@elmasco.eu | www.elmasco.eu